MOVING HEAD BEAM 230w

Ki-MH230



USER MANUAL

Ver.0.2

Kiki Lighting

CHANNEL	CHANNEL MODE	
	16	20
1	PAN	PAN
2	TILT	TILT
3	PAN FINE	PAN FINE
4	TILT FINE	TILT FINE
5	PAN-TILT TIME	PAN-TILT TIME
6	FROST	FROST
7	STOP/STROBE	STOP/STROBE
8	DIMMER	DIMMER
9	COLOUR WHEEL	COLOUR WHEEL
10	COLOUR Effect	COLOUR Effect
11	Gobo Change	Gobo Change
12	Gobo Effect	Gobo Effect
13	FOCUS	FOCUS
14	PRISM INSERTION	PRISM INSERTION
15	PRISM ROTATION	PRISM ROTATION
16	Lamp_Control&Reset	Lamp_Control&Reset
17	RFU	Macro Fuction
18	RFU	COLOUR TIME
19	RFU	DIMMER-PRISM-FROST TIME
20	RFU	GOBO TIME

Channels Detail

PAN - channel 1

TILT - channel 2

PAN FINE - channel 3

TILT FINE - channel 4

Pan-Tilt time-channel 5

Timing Channel	Channel function	Remark	
Pan-Tilt time	Pan-Tilt-(Pan fine-Tilt fine)	255	SLOW SPEED
		……	……
		0	FAST SPEED

FROST - channel 6

BIT	EFFECT	Remark
128-255	FROST INSERTED	FROST
0-127	FROST EXCLUDED	NO FROST

STOP/STOBE - channel 7

BIT	EFFECT	Remark
253-255	OPEN	
250－252	CLOSED	
241-249	OPEN	
240	FAST STROBE	
……	……	
51	SLOW STROBE	
1－50	OPEN	
0	CLOSED	

84	GOBO 12
77	GOBO 11
70	GOBO 10
63	GOBO 9
56	GOBO 8
49	GOBO 7
42	GOBO 6
35	GOBO 5
28	GOBO 4
21	GOBO 3
14	GOBO 2
7	GOBO 1
0	WHITE

Gobo_Effect- channel 12

BIT	EFFECT	Remark
191-255	FRU	
190	GOBO SHAKE, FAST SPEED	
……	……	
1	GOBO SHAKE, SLOW SPEED	

FOCUS - channel 13

BIT	EFFECT	Remark
255	Focus 100%	
……	……	
0	Focus 0%	

PRISM INSERTION - channel 14

BIT	EFFECT	Remark
32-255	PRISM INSERTED	
0-31	PRISM EXCLUDED	

PRISM ROTATION - channel 15

BIT	EFFECT	Remark
255	FAST ROTATION	
……	……	
192	SLOW ROTATION	
191	SLOW ROTATION	
……	……	
128	FAST ROTATION	
0-127	POSITION ADJUSTMENT	

LAMP CONTROL&RESET - channel 16

BIT	EFFECT	Remark
250-255	COMPLETE RESET	Reset is activated passing through the unused range and staying 5 seconds.
BIT	**EFFECT**	**Remark**
206-249	UNUSED RANGE	
200-205	LAMP ON	Lamp switch passing through the unused range and staying 5 seconds.
106-199	UNUSED RANGE	
100-105	LAMP OFF	
0-99	UNUSED RANGE	

MACRO FUNCTION - channel 17

BIT	EFFECT	Remark
0-5	UNUSED RANGE	
6-15	MACRO FUCTION 1	The Macro function 1-15 acts only on the Color, Gobo, Prism, and Prism Rotation.
……	……	
146-155	MARC FUCTION 15	
156-165	AUTO MODE 1	
166-175	AUTO MODE 2	The Macro function
176-185	AUTO MODE 3	

186-195	AUTO MODE 4	has priority over other channels. When the macro function is activited, the Channel1, channel2, channel5, and channel6 are invalid.
196-205	AUTO DRAW UP8	
206-215	AUTO DRAW FORWARD 0	
216-225	AUTO DRAW FORWARD STAND8	
226-235	AUTO DRAW FORWARD SLEEP8	
236-245	AUTO RUN RANDOM MODE	
246-255	SOUND CONTROL MODE	

TIMING CHANNELS

	Timing Channel	Channel function	Remark	
18	Colour time	Colour wheel	255	SLOW SPEED
19	Beam time	Dimmer-Prism -Frost	……	……
20	Gobo time	Static Gobo	0	FAST SPEED